

Model 600e

Ethernet Enabled

User's Manual



Table of Contents

1	Overview	1
1.1	Features and Benefits	1
2	Installation	1
2.1	Mounting	2
2.2	Powering the System	3
2.3	Wiring Inputs and Outputs	3
2.4	Input/Output Function	4
2.4.1	Input Definitions.....	5
2.4.2	Control Output Definitions.....	5
2.5	Remote Communication.....	6
2.6	RS485 End of Line resistor	6
2.7	Wiring Types	7
2.8	Typical installation drawings	7
3	Front Panel Display/Keypad Operation	12
3.1	Run Mode	12
3.1.1	Additional displays:	12
3.2	Comfort Mode	13
3.3	Lead Switch.....	13
3.4	Programming the Model 600e	13
3.5	Program Menus	14
3.5.1	System Menu*.....	14
3.5.2	Setpoint Menu.....	16
3.5.3	Economizer Menu	17
3.5.4	Alarm Menu.....	18
3.5.5	Bypass Menu	18
3.5.6	Run Option	19
4	Model 600e Web Server	19
4.1	Connecting to the System	19
4.2	Web Site Navigation	20
4.3	Home/Status Page.....	20

4.4	Alarm Page.....	22
4.5	Bypass Page	23
4.6	Setpoint Pages	24
4.6.1	HVAC Setpoints	25
4.6.2	Economizer Setpoints.....	27
4.6.3	Timer Settings	28
4.7	Settings	29
4.7.1	System Settings	30
4.7.2	Alarm Settings	31
4.7.3	Communications Settings.....	32
4.7.4	HTTP Password Settings.....	33
4.8	Logout.....	33
5	Sequence of operations	34
5.1	Lead/Lag vs. Lead/Standby control	34
5.1.1	Lead Switch	34
5.2	Controlling temperature.....	34
5.3	Fan control.....	35
5.4	Cooling Mode	35
5.5	Heating Mode	35
5.6	Economizer Control	36
5.6.1	Quest Econ Mode.....	36
5.6.2	Integrated Econ Control.....	37
5.6.3	No Economization	37
5.7	Dehumidification mode.....	37
6	Alarm Sequence of Operation.....	38
6.1	High Temperature Level 2	38
6.2	High Temperature Level 1	38
6.3	Low Temperature	38
6.4	High Humidity Alarm	38
6.5	HVAC Lockout	38
6.6	HVAC Control Voltage Lost.....	39
6.7	Smoke Alarm.....	39

6.8	Hydrogen Alarm.....	39
6.9	Generator Running.....	39
6.10	Fan Failure.....	39
6.11	Communications Loss.....	39
7	Remote Control Functions.....	40
7.1	Controlling Temperature.....	40
7.2	Outside Air Temperature.....	40
7.3	Operational Cooling Setpoint.....	40
7.4	Operational Econ Setpoint.....	40
7.5	Operational Heating Setpoint.....	41
7.6	Comfort Mode.....	41
7.7	Lead Switch Request.....	41
7.8	Econ Disable.....	41
7.9	HVAC Shutdown.....	41
7.10	HVAC Bypass Mode.....	41
7.11	Model 600e Control Mode.....	42
7.12	HVAC1 Mode.....	42
7.13	HVAC2 Mode.....	42
7.14	Remote Alarm Monitoring.....	42
8	Troubleshooting.....	43
9	Model 600e Specifications.....	44
	Appendix A – Modbus Register Map.....	45
	Appendix B – Control Output Matrix.....	53
	Contact Information.....	55
	Figure 1 - Enclosure Mounting Holes.....	2
	Figure 2- Model 600e Wiring Diagram.....	4
	Figure 3 – End of Line Resistor.....	6
	Figure 4 – Single Stage HVAC Typical Installation.....	8
	Figure 5 – Two Stage HVAC Typical Installation.....	9
	Figure 6 - Marvair HVESA Typical Installation.....	10
	Figure 7 – Bard H**4 System Wiring Diagram.....	11
	Figure 8 - Model 600e Keypad.....	12

Figure 9 - Programming Flow	14
Figure 10 - Log in Screen	19
Figure 11 – Model 600e Banner.....	20
Figure 12 – Status Page.....	21
Figure 13 – Alarms Page.....	22
Figure 14 – Bypass Page.....	23
Figure 15 – Restart Message.....	24
Figure 16 – HVAC Setpoints	25
Figure 17 – Additional HVAC Setpoints.....	26
Figure 18 – Econ Setpoints.....	28
Figure 19 – Timer Settings	28
Figure 20 – Restart Message.....	29
Figure 21 – System Settings	30
Figure 22 – Alarm Settings	31
Figure 23 – Communications Settings	32
Figure 24 – Web Server Passwords.....	33

CRITICAL APPLICATIONS DISCLAIMER

QUEST PRODUCTS ARE NOT INTENDED OR AUTHORIZED FOR USE IN ANY APPLICATION THAT REQUIRES FAIL-SAFE OPERATION, OR ANY SYSTEM THAT IS RESPONSIBLE FOR PROVIDING DETECTION, MONITORING OR CONTROL OF CRITICAL SAFETY, LIFESAVING OR LIFE-SUPPORT CONDITIONS, FUNCTIONS OR OPERATIONS (INCLUDING BUT NOT LIMITED TO FIRE DETECTION, ALARMING, OR SUPPRESSION), OR ANY APPLICATION WHEREIN A FAILURE OR MALFUNCTION OF THE PRODUCT MAY LEAD TO SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE, PERSONAL INJURY OR DEATH.

Revision History

Date	Rev #	Modifications	By:
08/01/25	1.0	Initial release of manual	K. Nickel

COPYRIGHT NOTICE

Copyright © 2025 by Quest Controls, Inc. (Quest). The material discussed in this publication is the proprietary property of Quest. Quest retains all rights to reproduction and distribution of this publication.

Specifications are subject to change without notice.

1 Overview

The Quest Controls Model 600e is designed to control two HVAC systems for lead/lag operation. The system supports heat pumps, single stage and two stage mechanical cooling systems that use a standard 24VAC control interface. The Model 600e will control HVAC units with built in economizers using control using Quest's patented Economizer Control Algorithm. The system is an easy-to-use lead/lag controller for small to medium-sized mission-critical facilities such as telecommunications, cable/broadband, and Utility facilities.

The Quest Controls Model 600e provides functionality and configurability to accommodate most conventional HVAC & heat pump applications. The application-specific approach ensures that commissioning is straightforward and hassle-free. The Model 600e contains internal programming logic to operate independently and can be configured to lock out local access to ensure programming integrity and ongoing correct control. The Model 600e remotely communicates through a 10/100Mb Ethernet RJ45 jack with a built-in web server. The system also supports Modbus TCP as well as Modbus RTU serial to Quest's ESB2, MP2 and MP3 systems or any Modbus polling agent.

1.1 Features and Benefits

- Controls two HVAC systems for Lead/Lag or Lead/Standby operation.
- Stand-alone or network operation to control HVAC systems.
- 10/100Mb Ethernet with built in web server
- Bluetooth interface for communication with the Quest iOS app.
- Modbus TCP and RTU communications
- Control based on one or two remote zone temperature sensors or both choosing the average or highest reading.
- Monitor up to zone temps, humidity, outside air, supply fan running, HVAC lockout, and control voltage present.
- Additional inputs for monitoring smoke detectors, generator running and hydrogen gas.
- Use industry-standard 10k type 3 thermistor.
- Backlight display - 2-line 16-character display for ease of use
- Adjustable Min & Max run time for stages
- 5 button keypad and display for easy programming plus keys for Lead Switch and Comfort Mode
- Lockout or limit user access via password on the front display and web server
- Temperature displayed in F or C

2 Installation

The Model 600e is designed to be wall-mounted inside the facility being controlled. This section will provide basic guidelines for installing the system. Refer to installation drawings for your application or contact Quest Controls, Inc. for help if your application is not covered in this section. All local and national electrical safety standards must be followed when installing the Model 600e. If there is any contradiction in this manual and those standards, then the installer must follow the local and national standards. Use copper conductors only.

2.1 Mounting

Remove the control board from the enclosure to access the mounting holes in the enclosure. Store the control board in a safe location and reinstall after the enclosure has been mounted and appropriate KO's have been removed for running cables. Mount the Model 600e on an interior wall in a location accessible for wiring and attainable to the display and keypad on the system's front. It is recommended to mount the controller no higher than six feet above the finished floor so that the display screen is easily accessible. Use appropriate mounting hardware (screws, anchors etc.) based on the wall material to properly secure the Model 600e to the wall. Knockouts are provided on all sides for conduit and routing of wires into the enclosure.




Figure 1 - Enclosure Mounting Holes

2.2 Powering the System

The Model 600e has three sources for powering the system. All three can be used simultaneously to provide redundancy to the system. The Model 600e gets 24VAC power from each HVAC system being controlled when the R (24vac hot) and C (24VAC common) terminals are connected to the system. The system monitors the presence of the 24VAC voltage from the HVAC unit to determine if power is lost, requiring a switch of the lead HVAC system. Additionally, there is a separate 18-65 VDC input on the upper left corner of the IO board for connection to a DC power plant. The DC power takes precedence over the power from the HVAC systems, but if any source should fail, the system will switch seamlessly to the next available source and continue to operate. The system monitors the presence of the 24VAC voltage from the HVAC unit to determine if power is lost, requiring a switch of the lead HVAC system.

2.3 Wiring Inputs and Outputs

See Figure 2- Model 600e IO Terminal Definitions and section 2.8 for wiring the monitoring and control points for your application. Temperature sensors are thermistor devices and are not polarity sensitive. For the Humidity sensor, make sure you wire the power and input terminals to the appropriate terminals. Follow the directions that come with the sensor. The alarm outputs are energized under normal conditions and de-energize when an alarm occurs. The diagram shows the outputs in their “normal” or non-alarm condition.

Monitoring inputs for HVAC fail, fan running, generator running, hydrogen gas and smoke detector are wired between their respective input and common terminal. The points are defined through the system setup and/or alarm setup (depending on input) for normally open or normally closed operation. The default value is “disabled” and must be changed if the points are wired and are being used.




Figure 2- Model 600e IO Terminal Definitions

2.4 Input/Output Function

The following matrix describes each input and output and what they are used for. Use this guide to determine how you want to wire your Model 600e system.

2.4.1 Input Definitions

Name	Description
Zone 1	Temperature sensor used for control and monitoring of the HVAC system and facility
Zone 2	An optional second zone sensor used for control and monitoring. Can be used with the Zone 1 sensor to control based on the highest reading or average reading
Humidity	4-20mA humidity sensor to monitor relative humidity in the facility and make control and alarm decisions.
Outside	Outside air sensor used for determining when to enable econ mode when using the Quest Econ control method
Smoke	Smoke detector input used to disable HVAC operation when active and to generate an alarm condition
H2 Gas	Hydrogen gas monitoring. Used to vent the facility and generate an alarm when active.
Gen Run	Generator Running input. Used to determine if econ should be disabled when active
Lockout	Lockout alarm for each HVAC unit. Causes system to switch the lead and generate an alarm condition
Fan Run	Normally open input that when the fan is running will have a contact closure present. Alarm delay available to notify of a failure condition. Fan fail does not cause a lead switch.

2.4.2 Control Output Definitions

Name	Description
G Fan	Supply Fan – On when call for heating or cooling, and if defined to run continuous
Y Cool1	Turns on when there is a call for cooling whether that be economizer or mechanical cooling
2 Econ DSBL	Turns on when the Model 600e is forcing mechanical cooling to be on.
W Heat	Turns on when there is a call for heating
Y2/O CL2/HTPMP	Stage two cooling if the Model 600e is defined to control two stage HVAC units. Also turns on, if the HVAC system type is defined as heat pump, when there is a call for cooling.
HVAC Lockout	Alarm output relay to indicate if either HVAC unit is in lockout mode.


2.5 Remote Communication

The Model 600e supports remote communications through ethernet, Bluetooth and Modbus RTU serial communications. For Ethernet connect a standard Cat 5 minimum cable to the Ethernet RJ45 port. The system supports communications with a standard web browser as well as Modbus TCP if enabled through the system setup page on the web server. Bluetooth communications is accomplished through Quest's iOS Bluetooth app. The app can be downloaded from the Apple App Store®.

The Model 600e supports Modbus RTU to communicate status and to allow for remote program changes. Use a three-wire cable to connect the Model 600e to the Modbus polling agent. The D0/D1 terminals should be wired using a twisted pair and the third wire will be used for a ground reference between the devices. Multiple Model 600e units can be daisy chained together for larger sites. Be sure that each Model 600e has a unique Modbus address and they are all configured for the same baud rate.

2.6 RS485 End of Line resistor

RS485 networks require an end of line resistor (EOL) to be present on the end devices of a daisy chain network. For a Model 600e at the end of the network, add a 120-ohm EOL resistor between D0 - and D1+ terminals.



2.7 Wiring Types

The following chart contains the recommended wire types for the inputs and outputs.

WIRE MATRIX		
Description	Cable Part Number	Usage
Cable, 2 Cond, 18 AWG, Unshld, Strnd (RED, BLACK)	Belden 6300UE	Power Supply to Model 600e and digital input monitor points
Cable, 2 Cond, 22 AWG, Shld, Solid (RED, BLACK)	Belden 6520FE	Temperature sensor and humidity inputs
Cable, 4 Cond, 20 AWG, Shld, Strnd 9 (RED, BLACK, WHITE, GREEN)	Belden 6402FE	Zone 1 combination temperature and humidity sensor.
Cable, 4 Pair, 24 AWG, Unshld, Solid	Belden 1245A2	Alarm outputs
Cable, 8 Cond, 18 AWG, Unshld, Solid, T-Stat	Coleman 55308	HVAC control wiring
Cable, 2 Pair, 24 AWG, Shld, Strand (WHT/BLU, BLU/WHT, WHT/ORG, ORG/WHT)	Belden 88102	Modbus RTU Cable





Table 1: Wire Matrix

2.8 Typical installation drawings


Below are some typical installation drawings for HVAC systems with Integrated Economizer control and when the Model 600e is controlling the economizer damper directly. Please contact Quest Controls for assistance if your application differs from these examples.

SINGLE STAGE NO ECON

OPTIONAL DC POWER INPUT



ZONE 1 TEMP AND HUMIDITY



ZONE 2 TEMP






Figure 4 – Single Stage HVAC Typical Installation




Figure 5 – Two Stage HVAC Typical Installation

MARVAIR HVESA 30-60 ACA 00 KW ICM VZ
 ENABLE ECONOMIZER CONTROL
 REFERENCES ARE TO MARVAIR DRAWING HVESA3660A0-ICM-VZ




Figure 6 - Marvaair HVESA Typical Installation




Figure 7 – Bard H**4 System Wiring Diagram

3 Front Panel Display/Keypad Operation

The Quest Model 600e has a 2X16 character backlit LCD and five buttons for status review and programming. Additionally, there are separate keys for lead switch and comfort mode operation. The backlight is normally off but will turn on when any key is pressed. The backlight will turn off after a few seconds of no keys being pressed. The first press of the keypad will turn on the backlight and tell the Model 600e to be ready for additional key presses. All keypad operations described below are after you press and release any key to enable the backlight.




Figure 8 - Model 600e Keypad

3.1 Run Mode

The display will show the controlling temperature reading, Which unit is the lead system and the HVAC control mode on the top line. The second line will show any active alarm condition or the message “NO ACTIVE ALARMS”. Press the up and down arrow keys to cycle through the various status screens to obtain current readings for all defined sensors and functionality.

3.1.1 Additional displays:

Press the up and down arrow keys to cycle through the status screens to obtain current readings for all defined sensors. The screens will show in the following order using the down arrow:

Screen	Description
Z <reading> Z2 <reading> H <reading> OSA <reading>	Shows the current reading of both zone sensors on line 1 and the humidity sensor and outside air sensor on line 2. A value of OER will be displayed if no sensor is connected to the input. If there is a sensor connected then OER would indicate an open reading. Check for broken wires. A reading of SER indicates a short to ground. The humidity sensor will show ERR% if there is an open or no sensor connected.

Screen	Description
SPTS E <value> C <value> H <value>	This screen will show the current setpoints for Econ, Cooling and Heating. Being used. Note the values shown are the active value and can change based on comfort mode or being remotely set through Modbus. The Econ setpoint will only be show if the Model 600e is defined to use Econ Mode.
Econ Ctrl Mode <value>	THE value will either be NONE, INTEGRATED or show the L1 and L2 econ setpoints for Quest Mode.
HVAC 1 <status> HVAC 2 <status>	The status of each HVAC unit showing what control mode the Model 600e is setting each HVAC to such as ECON 1, COOL1 etc.
HVAC 1 FAIL <ON OFF> HVAC 2 FAIL <ON OFF>	The on/off status of the HVAC lockout input for each unit.
HVAC 1 FanSt <ON OFF> HVAC 2 FanSt <ON OFF>	The on/off status of the supply fan feedback input.
SMOKE INP <ON OFF> HYDROGEN <ON OFF>	The on/off status of the smoke detector input and the hydrogen gas input.
GEN RUN <ON OFF>	The on/off status of the generator running input.

3.2 Comfort Mode

Press the comfort mode button to change the cooling and heating setpoints to a predefined value for a user defined timer period. The default time period is one hour. The display will display “Comfort Mode On” on the first line and resume normal status. When the unit is in comfort mode the message “COMFORT MODE ON” will be on the second line and will rotate with any active alarm messages.

Pressing the Comfort Mode button while in comfort mode will terminate comfort mode. The display will display “Comfort Mode Off” on the first line momentarily when the button is pushed.

3.3 Lead Switch

Pressing the Lead Switch button will manually switch which HVAC unit is the lead unit. The display will show “Lead to HVAC# where # = 1 or 2. The system will switch the lead provided the lag unit is not in an alarm condition that prevents the unit from operating such as control voltage lost or lock out alarm active. The unit switched to lead will remain in the lead position until the lead switch timer elapses or an alarm condition that causes a lead switch.

3.4 Programming the Model 600e

Press and hold the left and right arrow simultaneously until the display shows the enter password option. The default password is 11. Use the up/down arrow keys to change the password value and press the center button to log in. Passwords can be turned off or changed to any value from 11 to 99 via Modbus and the front panel System menu. From this menu use the up/down arrows to navigate to the available choices of: System, Setpoints, Economizer, Alarms, Bypass & Run. Choosing one of these options will present the available choices. Use the up/down arrows to cycle through the choices for

each field and the center button to accept the change and move to the next choice. Once you start in one of the program menus, you must step through all choices until the end to accept your changes. Press the center button to accept the current program value and go on to the next choice.




Figure 9 - Programming Flow

3.5 Program Menus

This section shows the program menus and available options. Items underlined indicate the default setting. All temperature values are shown in Fahrenheit.

3.5.1 System Menu*

System Option	Available Choices	Description
Temp Units	<u>Fahrenheit</u> , Celsius	Select the engineering units for displaying temperature and temperature setpoints
Control Sensor	<u>Zone 1</u> , Zone 2, High Zone 1 & 2, Avg Zone 1 & 2	Select the sensor to be used for control and alarming decisions. High will select the highest reading of the two and AVG will average the two sensors. This value will be shown on the main status screen as the controlling temperature.
HVAC type	<u>Single Stage DX</u> , Dual Stage DX, HP Energy Cool, HP Energy Heat	The type of HVAC system being controlled. Single stage cooling, two stage cooling, Heat pump energize the reversing valve for cooling and Heat pump energize the reversing valve for heating.
Lead/Lag Type	<u>Lead/Lag</u> , Lead/Standby	Lead/Lag allows both HVAC units to operate to maintain temperature. Lead/Standby will only allow one HVAC unit to operate at a given time.
Economizer	<u>None</u> , Integrated, Quest	Integrated assumes the HVAC unit has a built-in enthalpy controller that determines econ or mechanical cooling. Quest mode assumes the same but must also have an OSA sensor connected to take advantage of

System Option	Available Choices	Description
		advanced functionality with adaptive econ setpoint adjustment.
Gen Run Mode	<u>All Auto</u> , Econ Disable	All Auto = do nothing to HVAC when gen is running. Econ Disable will disable econ control mode. Gen Run input needs to be defined under Alarms for this operation to take effect.
Smoke Detect Mode	<u>All Off</u> , Econ Disable	Either turn off all HVAC or disable Econ Mode when the smoke detector is active. The smoke input needs to be defined under Alarms for this operation to take effect.
Fan Mode	<u>Auto</u> , Lead On, Both On	Auto = Fan is on with call for cooling or heating. Lead on = the lead unit's fan to constantly run Both on = both HVAC fans to run constantly.
Residual Fan Delay	0-180 seconds (<u>30</u>)	If a fan is defined as auto, then this is the delay after a call for cooling or heating before the fan turns off.
Restart Delay	0-900 seconds (<u>0</u>)	After a power failure to the Model 600e the system will wait for this delay before starting control operations.
Modbus Address	0-247 (<u>0</u>)	A value of 0 turns off Modbus communications
Baud Rate	9,600, <u>19200</u> , 38400, 57600, 76800	The baud rate required to communicate with a Modbus polling agent. Comm settings are fixed at 8n1.
Access Code	11-99 (<u>11</u>)	The access code to enter the program menus on the front panel
Prog Menu Access	<u>Allow</u> , Don't Allow	Allow access to the program menus on the front panel or lock out local access to programming.
Bluetooth Access	<u>Allow</u> , Don't Allow	Enables or disables the Bluetooth radio on the system for access via iOS app. See the Model 600e Bluetooth guide for additional information.
Ethernet Access	<u>Allow</u> , Don't Allow	Enables or disables Ethernet access.
IP Static/DHCP	<u>Static</u>	Select static IP or DHCP. If DHCP is selected, then the next fields will be the backup settings if DHCP fails to acquire an address
IP Address	<u>192.168.1.31</u>	The static IP address of the system
Netmask	<u>255.255.255.0</u>	The subnet mask setting
Gateway	<u>192.168.1.1</u>	The gateway address for sending data.
HTTP Port	<u>80</u>	The IP port number used when accessing the unit through a web browser.

*Changes made in the System Menu will cause the system to write to non-volatile flash memory and restart the Model 600e so it can operate with the new functionality.

3.5.2 Setpoint Menu

Setpoint Option	Available Choices	Description
Cool SPT	60-110 (<u>80</u>)	The setpoint value used for mechanical cooling
Econ SPT	60-110 (<u>75</u>)	The setpoint value used when econ mode is enabled.
CMFT Cool Delta	1-20 (<u>5</u>)	The number of degrees subtracted from the cool and econ setpoint when in comfort mode.
Cool Off Delta	1-20 (<u>2</u>)	The number of degrees below the cooling SPT (or econ spt if enabled) before turning off cooling.
Heat SPT	30-70 (<u>55</u>)	The setpoint value used for heating
CMFT Heat Delta	1-20 (<u>10</u>)	The number of degrees added to the heat setpoint when in comfort mode.
Heat Off Delta	1-20 (<u>2</u>)	The number of degrees the control temperature is above the heating setpoint to turn off heating.
RH Control SPT	20-100 (<u>0</u>)	When the %RH is above this setting, the system will go into dehumidification mode and use the dehumid setpoints for cooling and heating. A value of 0 disables this function.
RH Ctrl Off Delta	2-50 (<u>20</u>)	When using RH dehumid control the humidity sensor has to be below the RH Control SPT minus this value to disable Dehumid control mode
Dehumid Cool SPT	60-110 (<u>65</u>)	The cooling setpoint to use when in dehumidification mode.
Dehumid Heat SPT	30-70 (<u>65</u>)	The heating setpoint to use when in dehumidification mode.
Cool Stg 2 Delta	1-20 (<u>2</u>)	The number of degrees above the cool SPT to enter cool 2 mode.
Cool Stg 3 Delta	1-20 (<u>2</u>)	The number of degrees above the cool SPT plus stage 2 delta to enter cool 3 mode.
Cool Stg 4 Delta	1-20 (<u>2</u>)	The number of degrees above the cool SPT plus stage 2 and stage 3 deltas to enter cool 4 mode.
Heat Stg 2 Delta	1-20 (<u>2</u>)	The number of degrees below the heat setpoint to enter heat 2 mode.
Heat Stg 3 Delta	1-20 (<u>2</u>)	The number of degrees below the heat SPT minus stage 2 delta to enter cool 3 mode.
Heat Stg 4 Delta	1-20 (<u>2</u>)	The number of degrees below the heat SPT minus stage 2 and stage 3 deltas to enter cool 4 mode.
Lead Swtch Hours	0-336 (<u>168</u>)	The number of hours before switching the lead system. 0 = disable and will not switch leads based on time.
Comfort Minutes	0-240 (<u>60</u>)	The number of minutes for comfort mode to be active when the button is pressed. 0 disables comfort mode function

Stg Min On Time	30-600 (<u>120</u>)	The number of seconds that a cooling or heating stage must be on before it can be turned off to prevent short cycling.
Stg Min Off Time	30-600 (<u>120</u>)	The number of seconds to wait once a stage or cooling or heating is off before it can come back on.

3.5.3 Economizer Menu

Econ Option	Available Choices	Description
OSA L2 Setpoint	45-90 (<u>65</u>)	Quest mode – OSA above L2 disables econ mode.
OSA L1 Setpoint	45-90 (<u>65</u>)	Quest mode – OSA between L1 and L2 will enable both HVAC units in Econ mode (lead/lag mode only). OSA below L1 will enable the lead unit first and then if the inside temp rises, will enable the lag unit in econ mode.
OSA Float Maxchg	0-10 (<u>5</u>)	The maximum amount L1 and L2 can change up or down to automatically adjust based on success of econ mode.
OSA Dwell Time	60-900 (<u>60</u>)	How long to wait for the OSA temp reading to be above/below L1 and L2 to determine econ mode operation.
RH Disable SPT	0-100 (<u>0</u>)	The system will disable econ mode when the humidity is greater than this value. A value of 0 disables this function.

3.5.4 Alarm Menu

Alarm Option	Available Choices	Description
Hitemp2 Alarm SP	70-140 (<u>90</u>)	Alarm threshold for the High Temp alarm level 2 output. Level 2 alarm will cause a lead switch.
Hitemp1 Alarm SP	70-140 (<u>85</u>)	Alarm threshold for the High Temp alarm level 1 output.
Lowtemp Alarm SP	20-60 (<u>50</u>)	Alarm threshold for the low temperature alarm output.
Hihumid Alarm SP	0-100 (<u>0</u>)	Alarm threshold for a high humidity alarm condition. This alarm is available on the display and Modbus only. A value of 0 = disable.
Lockout Alarm	<u>Disable</u> , Normally Closed, Normally Open	HVAC lockout alarm. Select option based on how lockout alarm inputs are wired. Disable prevents the alarm condition from functioning.
Smoke Alarm	<u>Disable</u> , Normally Closed, Normally Open	Smoke alarm input. Select option based on the smoke detector input is wired. Disable prevents the alarm condition from functioning.
Hydrogen Alarm	<u>Disable</u> , Normally Closed, Normally Open	Hydrogen Sensor input. Select option based on how the input is wired. Disable prevents the alarm condition from functioning. This alarm is available on display and Modbus only.
Gen Run Alarm	<u>Disable</u> , Normally Closed, Normally Open	Generator Run input. Select option based on how the input is wired. Disable prevents the alarm condition from functioning. This alarm is available on display and Modbus only.
Fan Run Alarm	0-900 (<u>0</u>)	The number of seconds to wait before alarming when calling for the fan to run and the feedback input is OFF. A value of 0 = disable alarm.

3.5.5 Bypass Menu

The bypass function under the programming menu choices will allow for a temporary bypass condition of the HVAC systems to allow for testing and verification. Bypass overrides the current control mode and will force both HVAC units to the chosen control mode. The options are:

Heat2 – For heat pumps, Turns on the emergency heat, plus HP heat and the supply fan for both units.

Heat1 – Turns on heat plus the supply fan for both units.

Cool2 – Turns on cool stage 1 and 2 plus the supply fan for both units.

Cool1 – Turns on cool stage 1 plus the supply fan for both units.

Econ - Turns on the econ mode plus the supply fan for both units.

Off – turn both units off including the supply fan.

Select the control mode you want to bypass the system into and press the center button. The system will then allow you to use the up/down arrows to select the number of minutes for the bypass to take effect. The system will return to normal operation after the time expires or the operator can enter the bypass function again, select a bypass mode and leave the minutes at 0 and press the center button to cancel any bypass.

3.5.6 Run Option


Selecting Run puts the Model 600e back in run mode. Note: some changes require a restart. The Display will show “Restarting Soon” to indicate it is storing changes to flash and will reboot with the new configuration.

4 Model 600e Web Server

Connect a standard Ethernet cable between the TELSEC® ESB2 and your local Ethernet switch or router. You can also direct connect to the system with your PC using a static IP address on your PC. The Model 600e has a default IP address of 192.168.1.31. Use this address to log into the unit and then change the IP address to a new value. Alternatively, the IP address can be changed using the front panel. Log into the system and go to the Settings menu and select Communications to change the IP settings.

4.1 Connecting to the System

The built-in web server uses a *username* and *password* combination to authenticate a user and allow access. No information will be shown without proper authorization. The default setting uses a username of **Admin** and password of **admin**. The username and password are case sensitive so make sure your caps lock key is turned off. The default administrator password along with the two other passwords can be changed by going to Settings and clicking on HTTP Users. See section 4.7.4 for additional information on setting usernames, passwords and the supported access levels.



Sign in
http://192.168.1.31
Your connection to this site is not private

Username

Password

Figure 10 - Log in Screen

4.2 Web Site Navigation

All pages in the web server will have a banner across the top with the available menus. Hover your mouse over the menu choice to reveal the available sections for each category. The banner also contains an alarm bell that will be green when no alarms are present or will be red when there is an active alarm. Clicking on the alarm bell icon will take you to the Alarms page where you can view the available alarms with their current ON/OFF status. Clicking on the Quest Controls logo will open up a new browser tab showing Quest's web site. Additional information regarding the Model 600e or technical support can be found there.



Figure 11 – Model 600e Banner

4.3 Home/Status Page

Upon successful login, the web server will show the current status of the HVAC operation. This page will also be displayed when clicking on the Status option from the navigation menu. The page will color code the controlling temperature and mode based upon the following: Blue for cooling, Green for econ, white for off and orange for heating. In addition, the page will auto refresh approximately every 30 seconds.

The status page is broken down into three areas. The top section is the Site Overview and will display information such as the Controlling Temperature along with the current control mode. In addition there will be basic information regarding the configuration of the system such as: The HVAC type and economizer control type.

Below the Site Overview will be two boxes for HVAC 1 and 2 respectively. Here the page will show the detail status of the specific HVAC system. For example the Site Overview might say COOL1, but the individual HVAC blocks will show HVAC 1 in cool mode and HVAC 2 in OFF mode.

Site Overview

Controlling Temp

77°F

Zone 1	78°F
Zone 2	70°F
Outside	83°F
Humidity	13%RH

Lead System	1
Control Mode	OFF
Comfort Mode	OFF

Fan Mode	Lead On
HVAC Type	Two Stage DX2
Econ Type	Quest

HVAC 1 Status

Mode	OFF
Lockout	OFF
Control Voltage Loss	OFF
Fan Proof	ON
Emerg Vent Output	OFF


HVAC 2 Status

Mode	OFF
Lockout	OFF
Control Voltage Loss	OFF
Fan Proof	ON
Emerg Vent Output	OFF

Figure 12 – Status Page

4.4 Alarm Page

Clicking on the Alarms choice from the navigation menu or the alarm icon will display the alarm page. The page will list all the available alarms along with their current status. If a point is in alarm, it will have the value of ON and be shown in red. This page will refresh approximately every 30 seconds.



Alarm Status	
High Temp Level 2	ON
High Temp Level 1	ON
Low Temp	OFF
High Humidity	OFF
HVAC 1 Lockout	OFF
HVAC 2 Lockout	OFF
HVAC 1 Ctrl Volt Loss	OFF
HVAC 2 Ctrl Volt Loss	OFF
Smoke Detector	OFF
Hydrogen Gas Detector	OFF
Generator Running	OFF
HVAC 1 Sply Fan Fail	OFF
HVAC 2 Sply Fan Fail	OFF

Figure 13 – Alarms Page

4.5 Bypass Page

The bypass page is used to enable comfort mode, do a manual lead switch or temporarily bypass operation for testing. Clicking on the Comfort Mode button will enable or disable the comfort mode based on its current status. A popup will occur to notify the change has been made. Likewise clicking on the lead switch button will cause a popup to indicate the change has been made. This page refreshes approximately every 30 seconds.

The bypass HVAC function will allow the user to select the control mode and duration of the bypass in minutes. Select the control mode from the dropdown and then enter the number of minutes desired (or use the up/down arrows in the field). Then click on the Do Bypass button. To go back to automatic, enter a zero (0) in the duration time and click on the Do Bypass button again.

The image shows a user interface for HVAC bypass controls. It consists of three main sections:

- Comfort Mode:** A teal card with the title "Comfort Mode". It shows "Current Status" as "OFF" and an "Enable" button.
- Lead Switch:** A teal card with the title "Lead Switch". It shows "Current Lead" as "1" and a "Switch Lead" button.
- Bypass HVAC:** A larger teal card with the title "Bypass HVAC". It contains:
 - "Select Mode" dropdown menu set to "Heat 2".
 - "Duration (minutes)" input field set to "0".
 - "Do Bypass" button.
 - "Bypass Status" indicator showing "Not in Bypass".

Figure 14 – Bypass Page

4.6 Setpoint Pages

The pages under the menu options Setpoints allow the user to make changes to the current settings and save them to non-volatile flash. The web server will allow the user to make changes to a page and then click on the save button. A popup will occur announcing that the system will restart in a few minutes. There will also be a restart pending message in the header of the page. At this point the user can go to other pages under setpoints (or settings) and make additional changes. The restart timer will start over after each press of a Save button. Click on the Cancel button if you made changes to a page but decide not to save them. Once all changes are complete, you can either wait a couple minutes for the restart to occur automatically or click on the restart pending message to restart immediately. .



Figure 15 – Restart Message

4.6.1 HVAC Setpoints

Select Setpoints/HVAC to view and change the current HVAC Setpoints. Refer to section 3.5.2 for detail description for each value.

HVAC Setpoints	
Cooling Setpoint	80
Econ Setpoint	75
Comfort Mode Cooling Delta	5
Cooling Off Delta	2
Heating Setpoint	55
Comfort Mode Heating Delta	10
RH Control Setpoint	0

Figure 16 – HVAC Setpoints

Dehumidify Cool Setpoint
65

Dehumidify Heat Setpoint
65

Cool Stage 2 Delta
2

Cool Stage 3 Delta
2

Cool Stage 4 Delta
2

Heat Stage 2 Delta
2

Heating Off Delta
2

Heat Stage 3 Delta
2

Heat Stage 4 Delta
2

Save **Cancel**

Figure 17 – Additional HVAC Setpoints

4.6.2 Economizer Setpoints

Select Setpoints/Econ to view and change the current Setpoints for economizer control when using the Quest Econ control option. Refer to section 3.5.3 for detail description for each value.

Economizer Settings

Outside Air L2 Setpoint
65

Outside Air L1 Setpoint
62

L1/L2 Max Change
5

OSA Dwell Seconds
60


RH Econ Disable Setpoint
0

Save Cancel

Figure 18 – Econ Setpoints

4.6.3 Timer Settings

Select Setpoints/Timers to view and change the current timer settings. Refer to section 3.5.2 for detail description for each value.



The image shows a teal-colored dialog box titled "Timer Settings". It contains four input fields, each with a label above it and a value inside the field. The labels and values are: "Comfort Mode Minutes" with value "60", "Lead Switch Hours" with value "168", "Stage Minimum On Seconds" with value "120", and "Stage Minimum Off Seconds" with value "120". At the bottom of the dialog box are two buttons: "Save" and "Cancel".

Setting	Value
Comfort Mode Minutes	60
Lead Switch Hours	168
Stage Minimum On Seconds	120
Stage Minimum Off Seconds	120

Figure 19 – Timer Settings

4.7 Settings

The pages under the menu options Settings allow the user to make changes to the current settings and save them to non-volatile flash. The web server will allow the user to make changes to a page and then click on the save button. A popup will occur announcing that the system will restart in a few minutes. There will also be a restart pending message in the header of the page. At this point the user can go to other pages under settings (or setpoints) and make additional changes. The restart timer will start over after each press of a Save button. Click on the Cancel button if you made changes to a page but decide not to save them. Once all changes are complete, you can either wait a couple minutes for the restart to occur automatically or click on the restart pending message to restart immediately. .



Figure 20 – Restart Message

4.7.1 System Settings

Select Settings/System to view and change the current system settings. Refer to section 3.5.1 for detail description for each value.


The image shows a mobile application interface for 'System Settings'. The title 'System Settings' is at the top in white on a teal background. Below the title are several settings sections, each with a white header and a white input field on a teal background. The settings are: Temperature Units (Temp F), Control Scheme (Zone 1), HVAC Configuration (Single Stage DX1), HVAC Type (Lead/Lag), Econ Type (None), Fan Mode (Auto), Residual Fan Delay (30), Restart Delay (0), Smoke Detect Mode (All HVAC Units Off), Front Panel Access Code (11), and Front Panel Program Menu Access (Permit). At the bottom are two buttons: 'Save' and 'Cancel'.

Setting	Value
Temperature Units	Temp F
Control Scheme	Zone 1
HVAC Configuration	Single Stage DX1
HVAC Type	Lead/Lag
Econ Type	None
Fan Mode	Auto
Residual Fan Delay	30
Restart Delay	0
Smoke Detect Mode	All HVAC Units Off
Front Panel Access Code	11
Front Panel Program Menu Access	Permit

Figure 21 – System Settings

4.7.2 Alarm Settings

Select Setpoints/Alarms to view and change the current settings. Refer to section 3.5.4 for detail description for each value.



The screenshot displays the 'Alarm Settings' interface on a teal background. It features several settings, each with a label and a corresponding input field:

- High Temp Level 2:** Input field contains the value '90'.
- High Temp Level 1:** Input field contains the value '85'.
- Low Temp:** Input field contains the value '50'.
- High Humidity:** Input field contains the value '85'.
- HVAC Lockout:** Dropdown menu set to 'Disable'.
- Smoke Detect Input:** Dropdown menu set to 'Disable'.
- Hydrogen Gas Input:** Dropdown menu set to 'Disable'.
- Generator Run Input:** Dropdown menu set to 'Disable'.
- Fan Failure Seconds:** Input field contains the value '0'.

At the bottom of the screen, there are two buttons: 'Save' and 'Cancel'.

Figure 22 – Alarm Settings

4.7.3 Communications Settings

Select Setpoints/Communications to view and change the current settings. Refer to section 3.5.1 for detail description for each value. The Model 600e supports both Modbus TCP over Ethernet and RTU over a serial port. For Modbus TCP, the TCP address needs to be a value greater than 0. Some Modbus TCP clients required a specific address. The Model 600e will respond to any TCP request regardless of address, but an address value of 0 will turn off Modbus TCP. For Modbus RTU, the address must be the value the client will be polling. A value of 0 will turn off Modbus RTU.

The screenshot shows a teal-colored settings panel titled "Communication Settings". It contains several configuration fields:

- Modbus RTU Address:** A text input field containing the value "0".
- Modbus RTU Baud Rate:** A dropdown menu currently set to "19200".
- Modbus TCP Address:** A text input field containing the value "1".
- Modbus TCP Port Number:** A text input field containing the value "502".
- Static IP/DHCP:** A dropdown menu currently set to "Static IP".
- IP Address:** A text input field containing the value "192.168.1.31".
- Netmask:** A text input field containing the value "255.255.255.0".
- Gateway:** A text input field containing the value "192.168.1.1".
- HTTP Port Number:** A spinner control currently set to "80".

At the bottom of the panel are two buttons: "Save" and "Cancel".

Figure 23 – Communications Settings

4.7.4 HTTP Password Settings.

Select Settings/HTTP Users to display the available password options for the web server. The Model 600e supports three levels of passwords. The Status user has access to the Status and Alarms page, The Power user has status access plus access to the Bypass and Setpoints page. The Admin level user has access to all the pages. Enter the desired username and passwords for each level and then press the save button to save the values to flash. If you forget your Admin level password, the only way to gain access is to cold start the system to restore factory defaults and then reprogram the system.

The screenshot shows a teal-colored web interface titled "HTTP User Settings". It contains six input fields arranged vertically, separated by horizontal lines. The first field is "Status Username" with the value "User". The second is "Status Password" with masked characters "...." and a toggle icon. The third is "Power Username" with the value "Power". The fourth is "Power Password" with masked characters "....." and a toggle icon. The fifth is "Admin Username" with the value "Admin". The sixth is "Admin Password" with masked characters "....." and a toggle icon. At the bottom of the form are two buttons: "Save" and "Cancel".

Figure 24 – Web Server Passwords

4.8 Logout

The logout menu option will log off the current password. It is recommended to close your web browser before attempting to log back in with another password level.

5 Sequence of operations

This section will focus on the local control functions for the controller. Please see section 7 - Remote Control Functions for control functions when the unit exists in a network.

5.1 Lead/Lag vs. Lead/Standby control

The Model 600e will support two control methods which are Lead/Lag and Lead/Standby. The difference between the two is that Lead/Lag will allow both HVAC units to operate simultaneously whereas Lead/standby will only allow the lead unit to operate. The standby unit will only operate when it is switched to the lead unit based on the conditions identified in section 5.1.1.

5.1.1 Lead Switch

The system will not switch the lead system if the lag/standby unit is in a failed condition such as Lockout alarm or loss of control voltage. The system will switch the lead HVAC unit and clear the lead time remaining timer under the following conditions:

- The lead time hours have exceeded the lead time defined by the user.
- A user has pressed the Lead switch button.
- A Modbus write has occurred to the lead switch Modbus point.
- The current lead system has a lockout alarm.
- The current lead system has a control voltage loss alarm.
- The controlling temperature has exceeded the L2 high temperature alarm level.

5.2 Controlling temperature

The system will make all control for the HVAC system based upon the “controlling temperature”. The controlling temperature is defined in the system setup to be either zone sensor 1, zone sensor 2, the average of both sensors or the highest reading of the two sensors. If either zone 1 or 2 sensors are selected, the system will use that sensor provided there is a valid reading (between -25-150°F). If there is no valid reading then the system will report a sensor error on the display, turn both supply fans on and turn off heating and cooling.

When using the average or high of the two sensors, the system will use that function provided both sensors have valid readings. If one sensor is in error, then the Model 600e Controller will only use the sensor with valid readings. If there is no valid reading from either sensor then the system will report a sensor error on the display, turn the supply fans on and turn off heating and cooling.

The controlling temperature point will have write capability to allow the ESB2 (remote controller) to write a value to the point. The Model 600e Controller will use the written value for control unless a communications fault is detected. When a communications fault occurs, the controller will default back to the defined controlling temperature sensor mode. See section 7 for additional information on remote communications.

5.3 Fan control

The supply fan outputs are programmable from the display for continuous run for the lead system, both fans continually run or automatic mode. Automatic operation means the fan output is turned on when there is a call for heating, economization or cooling. For automatic mode, the fan will stay on until a user-definable delay after heating, econ or cooling is turned off. The Residual Fan Delay default is 30 seconds but is user selectable from 0-300 seconds.

5.4 Cooling Mode

Once a stage of cooling is turned on, it must remain on until the controlling temperature is below the cooling off setpoint (cool spt – cool off delta).

There are minimum on and minimum off time delays for each stage. These timers must elapse before there can be a change of state for the output relays. For example, if a mechanical cooling stage is off, it must be off for the minimum delay time before it allowed to be turned on. Once it is running, the cooling must continue to run for at least the minimum on time. The only exception is if there is an alarm condition that requires the cooling to be turned off such as a smoke alarm.

The Model 600e won't "jump" a cooling stage based on controlling temperature. As in, if the unit is off and calculations would like the unit to be in cool2, the unit will first try cool1 (or even econ if calculations allow) for the minimum on time before moving to cool2.

5.5 Heating Mode

The Model 600e Controller has two setpoints for heating mode. Heating stage 1 will be enabled when the controlling temperature is below the heating setpoint. If the temperature continues to lower to where the controlling temperature is below the heat 2 threshold (heating spt – heat 2 delta) then heat stage 2 will be enabled. Once a stage of heating is active, it must stay on until the controlling temperature is greater than the heating setpoint + heat off delta.

When controlling heat pumps, the Model 600e will have a total of four stages of heating. Stage 1 will be with the compressor running and the reversing valve either energized or de-energized based on the HVAC type definition. Stage 2 will be the auxiliary heat of the lead unit. Stage three will be the lag compressor running in heat mode followed by the auxiliary heat of the lag unit as stage 4.

The same minimum on and minimum off time delays apply for heating stages. These timers must elapse before there can be a change of state for the outputs. For example, if heating stage 1 is off, it must be off for the minimum delay time before it is turned on. Once it is turned on, it must continue to stay in the on state for at least the minimum on time. The only exception is if there is an alarm condition that requires the heating to be turned off such as a smoke alarm.

Also, note that the unit won't ever "jump" a heating stage based on controlling temperature. As in, if the unit is off and calculations would like the unit to be in heat2, the unit will first try heat1 for the normal on time before moving to heat2.

5.6 Economizer Control

The unit supports two types of economizations plus the option for no economizers. The options are “Quest” which requires an Outside air sensor connected to the Model 600e and integrated. Integrated will rely solely on the settings of the economizer controller inside the HVAC unit. When “Quest” mode is selected, the HVAC economizers (enthalpy controller) should be set to max OSA value so that the Model 600e can operate properly in econ mode. In Quest mode, the controller will use the outside air temperature reading and compare setpoints that can automatically adjust based on successfully cooling with outside air.

The outside air temperature Modbus point will have write capability to allow the ESB2 (remote controller) to write a value to the point. This way a single Outside air sensor can be used and shared amongst multiple controllers when Modbus is deployed. The Model 600e Controller will use the written value for control unless a communications fault is detected. When a communications fault occurs, the controller will default back to the defined controlling temperature sensor mode.

5.6.1 Quest Econ Mode

The Model 600e Controller will use Quest’s patented economizer control algorithm to maximize the amount of time outside air can be used for cooling the facility and will automatically adjust based upon changes to the facility or HVAC equipment. OSA temperature greater than L2 setting for the dwell delay will disable economization. OSA temperature between L1 and L2 for the dwell delay will enable econ mode in the lead and lag unit when there is a call for econ stage 1 mode. The reason for this is assuming both units are required to provide necessary airflow for free cooling when the outside air is at a higher value. OSA temperature below L1 for the dwell delay will allow the economizer for the lead system to be active when in Econ stage 1 and then will bring on the lag unit in econ mode if the inside temperature is above the econ setpoint plus the value in the stage 2 cooling delta. Floating of OSA setpoints is only available with Quest Econ mode and a valid outside air sensor reading.

It is recommended that when using Quest Econ Mode that the enthalpy controller of the HVAC unit be set to the highest available setting. This will allow the Model 600e to adjust its settings based on successful cooling with outside air without interference from the built-in enthalpy controller.

5.6.1.1 Adjusting OSA Setpoints

The Model 600e Controller will float/adjust the economizer OSA setpoint by using the Quest patented algorithm. Successfully cooling with OSA will move the L1 and L2 setpoints up. Failure to cool the zone with OSA only will cause the setpoints to adjust down. It is recommended that the differential between L1 and L2 be 3 to 5 degrees. The default is three degrees. An additional setting is provided called L1/L2 Max Change. This is the maximum allowable degrees that L1 and L2 will be allowed to move up or down. Both settings move together to maintain the differential.

5.6.2 Integrated Econ Control

Integrated economizer control means the economizer is being controlled by the HVAC system. The Model 600e Controller will decide to turn on stage 1 of cooling. The HVAC system will then decide to use economization or mechanical cooling. If temperature continues to rise, the Model 600e Controller will turn on output 2 to force mechanical cooling. This will cause the HVAC system to switch to mechanical cooling.

5.6.3 No Economization

The system allows for the option of NONE for the economization question. Choosing this option will disable all economizer logic and will control the mechanical cooling based upon the cooling setpoints.

5.7 Dehumidification mode

The dehumidification mode will be used to reduce the humidity inside the facility. When the relative humidity is greater than the dehumidification setpoint, the controller will change the operational cooling and heating setpoints to the Dehumidify cooling and heating setpoints. A user will typically move the cooling setpoint way down so the air conditioning can take moisture out of the air. A user can also move the heating setpoint to facilitate dehumidification. Economization will be disabled during dehumidification mode.

6 Alarm Sequence of Operation

All alarm conditions in this section will cause a message about the alarm to be displayed on line 2 of the local display. The display will rotate through all alarm messages if there is more than one active alarm condition. In addition, there are six form C outputs used for specific alarms. The outputs are energized under normal conditions and de-energized when in alarm.

6.1 High Temperature Level 2

The Model 600e Controller will compare the controlling temperature to the high temperature alarm L2 setpoint and alarm if the controlling temperature is greater than the setpoint for one minute. The alarm will clear when the controlling temperature is below the high temp L2 setpoint minus 2 degrees for 1 minute. Alarm Output 2 is used for High Temp Level 2 alarms along with an alarm message on the front display and status via Modbus.

6.2 High Temperature Level 1

The Model 600e Controller will compare the controlling temperature to the high temperature alarm L1 setpoint and alarm if the controlling temperature is greater than the setpoint for one minute. The alarm will clear when the controlling temperature is below the high temp L1 setpoint minus 2 degrees for 1 minute. Alarm Output 3 is used for High Temp Level 1 alarms along with an alarm message on the front display and status via Modbus.

6.3 Low Temperature

The Model 600e Controller will compare the controlling temperature to the low temperature alarm setpoint and alarm if the controlling temperature is less than the setpoint for one minute. The alarm will clear when the controlling temperature is above the low temp setpoint plus 2 degrees for 1 minute. Alarm Output 4 is used for Low temp along with an alarm message on the front display and status via Modbus.

6.4 High Humidity Alarm

The Model 600e Controller will compare the humidity sensor reading to the High Humidity alarm setpoint and alarm if the humidity is greater than the setpoint for one minute. The alarm will clear when the humidity is below the humidity alarm setpoint minus 5 (%rh) for 1 minute. This alarm condition will display on the front panel and have a Modbus register indicating an alarm.

6.5 HVAC Lockout

The Model 600e Controller will monitor the lockout alarm input based on the system configuration for both HVAC units. The system will enter the HVAC lockout alarm mode when the input is active for 5 seconds on either HVAC unit. When this input is active, the controller will turn off the mechanical cooling of the affected unit. In addition, if the affected unit is the lead, the Model 600e will switch to the lead unit. Alarm Output 1 is used to indicate a control voltage alarm has occurred on either unit along with an alarm message on the front display and status via Modbus.

If both HVAC units are in lockout, then the controller will turn on the Emergency Vent output(s) of each HVAC unit, along with the supply fan(s) to initiate emergency vent mode.

6.6 HVAC Control Voltage Lost

The Model 600e Controller will monitor the 24VAC control voltage for both HVAC units. The system will enter the Control Voltage Lost alarm mode when the voltage is not present for 5 seconds on either HVAC unit. When this input is active, the controller will turn off the mechanical cooling of the affected unit. In addition, if the affected unit is the lead, the Model 600e will switch to the lead unit. Alarm Output 6 is used to indicate a control voltage alarm has occurred on either unit along with an alarm message on the front display and status via Modbus.

6.7 Smoke Alarm

The system will enter smoke alarm mode when the input is active for 5 seconds. When this input is active, the controller will do the action defined under the system program menu which is to disable econ mode only on both units or to turn off both HVAC units completely. Alarm Output 5 will be used to indicate a smoke alarm along with an alarm message on the front display and status via Modbus.

6.8 Hydrogen Alarm

The system will enter hydrogen gas alarm mode when the input is active for 5 seconds. When this input is active, the controller will enable emergency vent mode on both HVAC units. Both units will remain in vent mode until the hydrogen gas alarm input is off and then will return to normal operation mode. An alarm message will be displayed on the front panel along with status via Modbus.

6.9 Generator Running

The system will monitor the generator for running and display an alarm message if the generator running input is on for 5 seconds along with status via Modbus. When the alarm is active, the Model 600e will disable operation of the HVAC systems based on the system defined function. The option is to disable econ mode for both HVAC units or operate both units normally.

6.10 Fan Failure

The system will monitor the fan run input for each HVAC and generate an alarm if there is a call for the fan to be running and the fan run input is not active (ON) after the defined delay. The alarm condition will stay present until the fan input is active (ON) while the system is call for the fan to run. This alarm is a notification only and will not cause a lead switch.

6.11 Communications Loss

If the Model 600e is defined for Modbus communications by changing the Modbus address from 0, it will monitor for communications on the serial port. If no communications have been received for two minutes, then any remote commands previously sent will be ignored and the system will go back to local operation. A message will be on the display indicating communications loss.

7 Remote Control Functions

The Model 600e control and monitoring functions can be modified through Modbus TCP or RTU. All setpoints and system settings are available to be read or changed along with the ability to gather status from all inputs and outputs. Review the Modbus map (appendix A) for the available registers and functionality.

The Model 600e will accept writes to certain registers from a remote agent. Some of the registers being written to are only used while the unit is communicating. When communications are lost for two minutes, the Model 600e will revert to local control mode. This section will discuss those registers that can be set remotely but return to local default when the unit is reset, or communications are lost. Note, if you are going to use this function, it is recommended that you choose to enable either Modbus RTU (serial) or Modbus TCP. Having both enabled may have unintended results if both protocols do not communicate with the Model 600e within the two-minute time frame. See section 4.7.3 for enabling/disabling Modbus TCP and RTU.

7.1 Controlling Temperature

The controlling temperature register is holding register 100. This register will show the value of the sensor(s) being used to make control decisions. For example, if the Model 600e has two zone sensors and is configured to average those sensor readings, then the value of register 100 will be the average of those two sensors. This register can also be written to by a polling agent to change the value of the controlling temperature. An example of this function would be to calculate the average of multiple sensors connected to other devices and then set the controlling temperature based on that average.

7.2 Outside Air Temperature

Modbus holding register 101 is used to tell the Model 600e what the outside air temperature is so that the unit can determine if economizer mode can be used. This register would normally display the value of the outside air temperature on the Model 600e, but this register can also be written to so that a single OSA sensor can be used on one device and be sent to other Model 600e units by the Modbus polling agent.

7.3 Operational Cooling Setpoint

Modbus holding register 102 is used to display the current cooling setpoint. This will either be the locally stored value, or a polling agent can write a value to this register. Write the desired cooling setpoint to this register when you want to coordinate Lead/Lag operation between multiple units and or change the setting based on time or occupancy. Writing a value of 65535 will cause the Model 600e to use the locally stored value of Modbus register 1100.

7.4 Operational Econ Setpoint

Modbus holding register 103 is used to display the current economizer cooling setpoint. This will either be the locally stored value, or a polling agent can write a value to this register. Write the desired econ cooling setpoint to this register when you want to coordinate Lead/Lag operation between multiple units and or change the setting based on time or occupancy. Writing a value of 65535 will cause the Model 600e to use the locally stored value of Modbus register 1101.

7.5 Operational Heating Setpoint

Modbus holding register 104 is used to display the current heating setpoint. This will either be the locally stored value, or polling agent can write a value to this register. Write the desired heating setpoint to this register when you want to coordinate Lead/Lag operation between multiple units and or change the setting based on time or occupancy. Writing a value of 65535 will cause the Model 600e to use the locally stored value of Modbus register 1104.

7.6 Comfort Mode

Modbus holding register 107 is used to remotely set the unit into comfort mode. Write a 1 to enable comfort mode which will then time out based up the defined comfort mode time. Write a 0 to disable comfort mode.

7.7 Lead Switch Request

Modbus holding register 108 is used to which HVAC unit is the current lead system. Writing a value greater than zero will switch the lead unit. Writing a 0 will resume local operation.

7.8 Econ Disable

Holding register 109 is used to disable the economizer mode on a Model 600e. Writing a value greater than 0 will disable economizer operation. Writing a 0 to the register will allow the Model 600e to continue economizer operation as needed.

7.9 HVAC Shutdown

Holding register 110 is used to force both HVAC units to off mode. Writing a value greater than zero will force off the HVAC units. Writing a 0 will resume local operation.

7.10 HVAC Bypass Mode

Holding register 106 is used to enumerate the current control mode of the HVAC systems. For example, a value of 4 equals econ 1 mode. Writing to this register will override the current control mode and force the HVAC units to a specific control mode. Writing to this register requires two pieces of information. The high byte is the number of minutes for the bypass and the low byte is the desired mode. For example, if you want to bypass to cool 2 mode for 60 minutes then you would write the value 15366, which is calculated as follows:

High byte Hex value of minutes + low byte Hex value of mode = The register value in Hex. Then convert the value to decimal.

60 minutes = 3c hex + 06 for Cool 2 mode = 3c06 hex which equals decimal 15366.

Tip: you can use the built-in Windows calculator in programmer mode to do the calculations.

The Model 600e will count down and return to automatic mode at the end of the bypass time. Alternatively, you can write a 0 to the register to clear the bypass.

7.11 Model 600e Control Mode

Holding register 105 is used to enumerate the current overall control mode of the Model 600e. The register holds the mode value where: 1 = Heat4, 2 = Heat3, 3 = Heat2, 4 = Heat1, 5 = OFF, 6 = Econ1, 7 = Econ2, 8 = Cool 1, 9 = Cool 2, 10 = Cool3, 11 = Cool4. This register is read-only.

7.12 HVAC1 Mode

Holding register 113 is used to enumerate the current control mode and bypass state of the HVAC1 system. The register holds the mode value where: 1 = Heat2, 2 = Heat1, 3 = Off, 4 = Econ, 5 = Cool 1, 6 = Cool 2). This register is read-only.

7.13 HVAC2 Mode

Holding register 114 is used to enumerate the current control mode and bypass state of the HVAC2 system. The register holds the mode value where: 1 = Heat2, 2 = Heat1, 3 = Off, 4 = Econ, 5 = Cool 1, 6 = Cool 2). This register is read-only.

7.14 Remote Alarm Monitoring

The Model 600e has built-in alarm monitoring functions to determine when an alarm condition is present and will display the alarm on the front panel and make the corresponding register have a value of 1. Registers 200-212 contain the available alarm status points. Writing any value to the register will clear the alarm condition which will change the register value to 0 and clear the message from the display. The alarm will not occur again until the problem clears and occurs again.

8 Troubleshooting

LCD Screen is dark and no characters are displayed

Verify power is present from each HVAC unit between the R and C terminals. Also verify the DC power input if being used.

Controlling Sensor reads OER or SER

The zone sensor(s) used for controlling the HVAC unit are either shorted to ground (SER) or are open (OER). Check the wiring and terminations for possible shorts or broken connections. Note if no sensor is terminated to Zone 2 (the remote sensor) then it is normal for the reading to be OER for the input. If the controlling sensor reads OER then make sure Z2 is not chosen as the sensor for control when it is not physically present.

Model 600e mode says Cool1, but the compressor does not engage

Verify the connection to HVAC unit. Ensure the short-cycle timer is not inhibiting the unit.

Model 600e won't communicate to the Modbus polling agent

Verify the wiring and polarity. Verify the Modbus address and baud rate. Verify that all Model 600es on the network have a unique address.

Buttons do not respond

Press buttons slowly, some functions may take pressing the button twice.

Display is corrupted

First, cycle power to the unit or do a warm start to the system (see below). If the problem persists then do a cold start by following the cold start process below.

Warm start (reset) the system

Press and release the white button below the display panel to perform a warm start. This will restart the system without changing any values/setpoints written to flash.

Cold start (factory restore)

Locate the small black button (sw2) on the lower left side of the board and hold it in while pressing and releasing the white warm start (SW1) button. Continue to hold in the black button while the display shows "Cold Sense". Once the display shows "Cold Start" you can release the button. The system has now been restored to factory default settings.

9 Model 600e Specifications

Specifications

Part Number	151112
Mounting	Wall mount
Enclosure	Color: Grey Material: Polycarbonate with knockouts on all sides
Inputs	Digital Inputs: (2) 24vac input from HVAC, (7) dry contact closures. Analog Inputs: Temperature sensors (3) Thermistors sensor $\pm 1^{\circ}\text{F}$ (0.5°C) 4-20mA Input (1) – Relative Humidity Sensor
Outputs	Control Digital Outputs: (12) 30V AC max, 1A continuous, 3A in-rush Alarm Outputs: (6) Form C dry contracts. Supports 48VDC @ 0.5A
Power	24VAC from both HVAC units and separate 24/48VDC simultaneously
LCD Display	Type: Backlit LCD display Display Area: 2 rows of 16 characters each
Keypad	Four button directional arrows, enter button plus Comfort Mode and Lead Switch
Communication	Ethernet 10/100Mb, RS485 Modbus RTU, Bluetooth
Environmental	Operating Temperature: 0°C to 50°C; 32°F to 122°F Storage Temperature: -30°C to 50°C; -22°F to 122°F Relative Humidity: 0 to 95% non-condensing
Dimensions	7.09" W x 10" H x 2.8" D (180 x 254 x 71 mm)
Weight	2.2 lb. (1 kg)
Warranty	1 year

Specifications are subject to change without notice.

Appendix A – Modbus Register Map

Any register defined as read/write (RW) and with a Y under the Non-volatile column will cause a system restart when written too. This is a normal practice to ensure that any new configuration setting is saved to flash memory and then used by the system. When you write to a non-volatile register, the Model 600e starts a countdown timer of two minutes before reset to allow writing to additional non-volatile registers. Writing to subsequent registers will restart the countdown timer. Once the countdown timer has elapsed, the system will restart and use the new settings.

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
Analog Inputs							
Input Register (FC4)	0	Zone 1 Thermistor Temp	RO	sword	N/A	Integer value 327 to -327	N
	1	Zone 2 Thermistor Temp	RO	sword	N/A	Integer value 327 to -327	N
	2	Humidity sensor	RO	sword	N/A	Integer value 0 to 100	N
	3	Outside Air Sensor	RO	sword	N/A	Integer value 327 to -327	N
	100	Zone 1 Thermistor Temp (hundredths)	RO	sword	N/A	Integer value 32727 to -32727	N
	101	Zone 2 Thermistor Temp (hundredths)	RO	sword	N/A	Integer value 32727 to -32727	N
	102	Humidity sensor (hundredths)	RO	sword	N/A	Integer value 32727 to -32727	N
	103	Outside Air Sensor (hundredths)	RO	sword	N/A	Integer value 32727 to -32727	N
	200	Zone 1 Thermistor Temp	RO	float	N/A	IEEE754 Floating point (32 bits)	N
	202	Zone 2 Thermistor Temp	RO	float	N/A	IEEE754 Floating point (32 bits)	N
	204	Humidity sensor	RO	float	N/A	IEEE754 Floating point (32 bits)	N
	206	Outside Air Sensor	RO	float	N/A	IEEE754 Floating point (32 bits)	N
Digital Inputs							
Discrete Input (FC2)	0	HVAC 1 Lockout	RO	bit	N/A	0 = off and 1 = on based on Reg 1204	N
	1	HVAC 2 Lockout	RO	bit	N/A	0 = off and 1 =on based on Reg 1204	N
	2	HVAC 1 Control Voltage Loss	RO	bit	N/A	0 = off and 1 =on	N

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
	3	HVAC 2 Control Voltage Loss	RO	bit	N/A	0 = off and 1 =on	N
	4	HVAC 1 Fan Status	RO	bit	N/A	0 = off and 1 =on	N
	5	HVAC 2 Fan Status	RO	bit	N/A	0 = off and 1 =on	N
	6	Smoke Detector Status	RO	bit	N/A	0 = off and 1 =on based on Reg 1205	
	7	Hydrogen Sensor Status	RO	bit	N/A	0 = off and 1 =on based on Reg 1206	
	8	Gen Run Status	RO	bit	N/A	0 = off and 1 =on based on Reg 1207	
Digital Outputs							
Read coil/output (FC1)	0	HVAC 1 Fan (G)	RO	bit	N/A	0 off, 1 on	N
	1	HVAC 1 Cooling (Y1)	RO	bit	N/A	0 off, 1 on	N
	2	HVAC 1 Force Mech Cooling (2)	RO	bit	N/A	0 off, 1 on	N
	3	HVAC 1 Heating (W)	RO	bit	N/A	0 off, 1 on	N
	4	HVAC 1 Cool2/Heat Pump (Y2/O)	RO	bit	N/A	0 off, 1 on	N
	5	HVAC 1 Emerg Ven Mode (MAR)	RO	bit	N/A	0 off, 1 on	N
	6	HVAC 2 Fan (G)	RO	bit	N/A	0 off, 1 on	N
	7	HVAC 2 Cooling (Y1)	RO	bit	N/A	0 off, 1 on	N
	8	HVAC 2 Force Mech Cooling (2)	RO	bit	N/A	0 off, 1 on	N
	9	HVAC 2 Heating (W)	RO	bit	N/A	0 off, 1 on	N
	10	HVAC 2 Cool2/Heat Pump (Y2/O)	RO	bit	N/A	0 off, 1 on	N
	11	HVAC 2 Emerg Ven Mode (MAR)	RO	bit	N/A	0 off, 1 on	N
	12	HVAC Lockout Alarm	RO	bit	N/A	1 off, 0 on. Output energized when not in alarm.	N
	13	High Building Temp L2 Alarm	RO	bit	N/A	1 off, 0 on. Output is energized when not in alarm.	N
	14	High Building Temp L1 Alarm	RO	bit	N/A	1 off, 0 on. Output is energized when not in alarm.	N
	15	Low Building Temp Alarm	RO	bit	N/A	1 off, 0 on. Output is energized when not in alarm.	N
	16	Smoke Alarm	RO	bit	N/A	1 off, 0 on. Output is energized when not in alarm.	N

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
	17	Control Voltage Lost Alarm	RO	bit	N/A	1 off, 0 on. Output is energized when not in alarm.	N
Operation/Status							
Holding Register (FC3/6/16)	100	Controlling Temperature	RW	word		Write will override internally calculated value based on Reg 1001. Write of 65535 will resume local operation.	N
	101	Outside Air Temperature	RW	word		Write will override internally calculated value. Write 65535 will resume local operation.	N
	102	Operational Cooling Setpoint	RW	word		Write will override internally calculated value. Write 65535 will resume local operation.	N
	103	Operational Econ Setpoint	RW	word		Write will override internally calculated value. Write 65535 will resume local operation.	N
	104	Operational Heating Setpoint	RW	word		Write will override internally calculated value. Write 65535 will resume local operation.	N
	105	Model 600e Control Mode	R	word	N/A	Enumerated low byte: 1 = Heat 4, 2 = Heat 3, 3 = Heat 2, 4 = Heat 1, 5 = Off, 6 = Econ 1, 7 = Econ 2, 8 = Cool 1, 9 = Cool 2, 10 = Cool 3, 11 = Cool 4	N
	106	HVAC Bypass Mode	RW	word	N/A	Enumerated low byte: 1 = Heat 2, 2 = Heat 1, 3 = Off 4 = Econ, 5 = Cool 1, 6 = Cool 2 High byte is the number of minutes for bypass or 0 for return to local operation.	N
	107	Comfort Mode	RW	word	0	Not 0 = enable comfort mode 0 = disable comfort mode	

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
	108	Lead Switch	RW	word	0	not 0 = Switch 0 = resume local operation (reading gives 1 or 2)	N
	109	Econ Disable	RW	word	0	not 0 = Disable economizer, 0 = resume local operation	N
	110	HVAC Shutdown	RW	word	0	0 = Remove remote shutdown, not 0 = Enable remote shutdown	N
	111	Adjusted Outside Air L2 Setpoint	RO	word		Current L2 setpoint with adjustments	N
	112	Adjusted Outside Air L1 Setpoint	RO	word		Current L1 setpoint with adjustments	N
	113	HVAC1 Stage Mode	RO	word	N/A	Enumerated low byte: 1 = Heat 2, 2 = Heat 1, 3 = Off, 4 = Econ, 5 = Cool 1, 6 = Cool 2. High byte is the number of minutes for bypass or 0 if not in bypass	N
	114	HVAC2 Stage Mode	RO	word	N/A	Enumerated low byte: 1 = Heat 2, 2 = Heat 1, 3 = Off, 4 = Econ, 5 = Cool 1, 6 = Cool 2. High byte is the number of minutes for bypass or 0 if not in bypass	N
Alarm Status							
Holding Register (FC3/6/16)	200	High Level 2 temperature alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	201	High Level 1 temperature alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	202	Low temperature alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	203	High Humidity Alarm	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	204	HVAC 1 Lockout alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	205	HVAC 2 Lockout alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	206	HVAC 1 Control Voltage Loss	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
	207	HVAC 2 Control Voltage Loss	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	208	Smoke alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	209	Hydrogen alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	210	Generator running alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	211	HVAC 1 Fan Failure alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
	212	HVAC 2 Fan Failure alarm status	RW	word	0	0 = inactive, 1 = active, any write clears active alarm	N
Configuration							
Holding Register (FC3/6/16)	1000	Temperature Units	RW	word	0	0 = F, 1 = C	Y
	1001	Control Sensor Scheme	RW	word	0	Enumerated: 0 = use zone 1 sensor, 1 = use zone 2 sensor, 2 = use average of both sensors, 3 = use high of both sensors	Y
	1002	HVAC Type	RW	word	0	0 = dx1, 1 = dx2, 2 = hp En Cool, 3 = hp En Heat	Y
	1003	HVAC Control	RW	word	0	0 = Lead/Lag, 1 = Lead/Standby	Y
	1004	Economizer Type	RW	word	0	0 = none, 1 = Quest, 2 = integrated	Y
	1005	Fan Mode	RW	word	0	0 = auto, 1 = Lead always on, 2 = both always on	Y
	1006	Residual Fan Delay	RW	word	30	0-300 seconds	Y
	1007	Restart Delay	RW	word	0	0-900 seconds	Y
	1008	Gen Run Mode	RW	Word	0	0= All Auto, 1 = Econ disabled.	Y
	1009	Smoke Detect Mode			0	0=ALL HVAC units OFF, 1=Econ mode disabled.	Y
	1010	Modbus Address	RW	word	0	0-247	Y

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
	1011	Baud Rate	RW	word	1	Enumerated: 0 – 9600, 1 – 19200, 2 – 38400, 3 – 57600, 4 – 76800	Y
	1012	Front Panel Access Code	RW	word	11	0 = disable, 11-99 to enable	Y
	1013	Front Panel Program Menu Lockout	RW	word	0	0 = allow, 1 = don't allow	Y
	1014	Modbus TCP Address	RW	word	0	0-247	Y
	1015	Modbus TCP Port Number	RW	word	0	0-65535	Y
Local Setpoints							
Holding Register (FC3/6/16)	1100	Cooling Setpoint	RW	word	80	60-110 degrees	Y
	1101	Econ Setpoint	RW	word	75	60-110 degrees	Y
	1102	Comfort Mode Cooling delta	RW	word	5	1-20 degrees	Y
	1103	Cooling off delta	RW	word	2	1-20 degrees	Y
	1104	Heating Setpoint	RW	word	55	30-70 degrees	Y
	1105	Comfort Mode Heating Delta	RW	word	10	1-20 degrees	Y
	1106	%RH control setpoint	RW	word	0	20-100%RH, 0= disabled	Y
	1107	%RH control off delta	RW	word	20	2-50%RH	Y
	1108	Dehumidify Cool SPT	RW	word	65	60-110	Y
	1109	Dehumidify Heat SPT	RW	word	65	30-70	Y
	1110	Cool stage 2 delta	RW	word	2	1-10 degrees	Y
	1111	Cool stage 3 delta	RW	word	2	1-10 degrees	Y
	1112	Cool stage 4 delta	RW	word	2	1-10 degrees	Y
	1113	Heat stage 2 delta	RW	word	2	1-10 degrees	Y

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
	1114	OSA L2 SPT	RW	word	65	45-90 degrees	Y
	1115	OSA L1 SPT	RW	word	62	45-90 degrees	Y
	1116	L1/L2 Max Change	RW	word	5	0-10 degrees	Y
	1117	OSA Dwell Seconds	RW	word	60	60-900 seconds	Y
	1118	RH Econ Disable SPT	RW	word	0	0-100 percent, 0 = disable	Y
	1119	Comfort Mode Minutes	RW	word	60	0-240 Minutes, 0 = disable	Y
	1120	Lead Switch Hours	RW	word	168	0-336 hours, 0 = disable	Y
	1121	Stage Min On Secs	RW	word	120	30-600 Seconds	Y
	1122	Stage Min Off Secs	RW	word	120	30-600 Seconds	Y
	1123	Heating off delta	RW	word	2	1-20 degrees	Y
	1124	Heat stage 3 delta	RW	word	2	1-10 degrees	Y
	1125	Heat stage 4 delta	RW	word	2	1-10 degrees	Y
Alarm Settings							
	1200	High temperature level 2	RW	word	90	70-140 = degrees	Y
	1201	High temperature level 1	RW	word	85	70-140 = degrees	Y
	1202	Low temperature level	RW	word	50	20-60 = degrees	Y
	1203	High Humidity Alarm	RW	word	0	0-100 = %RH (0 disables)	Y
	1204	HVAC Lockout	RW	word	0	Enumerated: 0 = disable, 1 = normally open (closure alarms), 2 = normally closed (open alarms)	Y
	1205	Smoke Alarm input	RW	word	0	Enumerated:	Y

Function Code	Register	Description	Read/Write	Type	Default	Notes	Non-volatile
						0 = disable, 1 = normally open (closure alarms), 2 = normally closed (open alarms)	
	1206	Hydrogen Gas Alarm Input	RW	word	0	Enumerated: 0 = disable, 1 = normally open (closure alarms), 2 = normally closed (open alarms)	Y
	1207	Generator Run Alarm Input	RW	word	0	Enumerated: 0 = disable, 1 = normally open (closure alarms), 2 = normally closed (open alarms)	Y
	1208	Fan Failure Alarm seconds	RW	word	0	0-1800 (0 disables)	Y
Misc.	1300	Product ID	RO	word	601	601	N
	1301	Firmware Revision	RO	word		A.B.C.D in 4-bit numbers	N
	1302	Reset	RW	word		Must write 57005 to data register for reset	N

Appendix B – Control Output Matrix

The following matrixes show which outputs are on for the various control modes displayed on the front panel and available through Modbus. The ECON control modes are only present when the System Setup has “Integrated” or “Quest Econ” mode enabled.

Single Stage DX				
Mode	Lead/Lag Mode		Lead/Standby Mode	
	Lead	Lag	Lead	Standby
ECON1	G, Y1		G, Y1	
ECON2	G, Y1	G, Y1		
COOL1	G, Y1, 2		G, Y1, 2	
COOL2	G, Y1, 2	G, Y1, 2		
HEAT1	G, W		G, W	
HEAT2	G, W	G, W		

Two Stage DX				
Mode	Lead/Lag Mode		Lead/Standby Mode	
	Lead	Lag	Lead	Standby
ECON1	G, Y1		G, Y1	
ECON2	G, Y1	G, Y1	G, Y1	
COOL1	G, Y1, 2		G, Y1, 2	
COOL2	G, Y1, 2, Y2		G, Y1, 2, Y2	
COOL3	G, Y1, 2, Y2	G, Y1, 2		
COOL4	G, Y1, 2, Y2	G, Y1, 2, Y2		
HEAT1	G, W		G, W	
HEAT2	G, W	G, W		

Heat Pump Reverse Valve Energized Cooling				
Mode	Lead/Lag Mode		Lead/Standby Mode	
	Lead	Lag	Lead	Standby
ECON1	G, Y1, Y2/O		G, Y1, Y2/O	
ECON2	G, Y1, Y2/O	G, Y1, Y2/O		
COOL1	G, Y1, 2, Y2/O		G, Y1, 2, Y2/O	
COOL2	G, Y1, 2, Y2/O	G, Y1, 2, Y2/O		
HEAT1	G, Y1, 2		G, Y1, 2	
HEAT2	G, Y1, 2, W		G, Y1, 2, W	
HEAT3	G, Y1, 2, W	G, Y1, 2		
HEAT4	G, Y1, 2, W	G, Y1, 2, W		

Heat Pump Reverse Valve Energized Heating				
	Lead/Lag Mode		Lead/Standby Mode	
Mode	Lead	Lag	Lead	Standby
ECON1	G, Y1		G, Y1	
ECON2	G, Y1	G, Y1		
COOL1	G, Y1, 2		G, Y1, 2	
COOL2	G, Y1, 2	G, Y1, 2		
HEAT1	G, Y1, 2, Y2/O		G, Y1, 2, Y2/O	
HEAT2	G, Y1, 2, Y2/O, W		G, Y1, 2, Y2/O, W	
HEAT3	G, Y1, 2, Y2/O, W	G, Y1, 2, Y2/O		
HEAT4	G, Y1, 2, Y2/O, W	G, Y1, 2, Y2/O, W		

Contact Information

Website:

www.questcontrols.com

Email:

General information: info@questcontrols.com

Technical support: CustomerService@questcontrols.com

Mailing Address:

Quest Controls, Inc.

208 9th Street Dr. West, Palmetto FL 34221

Key Phone Numbers

Main Number: (941) 729-4799

Sales/Sales support: option 1.

Technical & Applications Support: option 3.

Repair and RMA Support: option 5.

Fax: (941) 729-5480